

KOHLER. Faucets. Live Bold.







The Response... technology of the Sensate... touchless kitchen faucet responds to your every move, leaving you to wonder how you ever prepped, cleaned and cooked without it.

Sensate kitchen faucet frees your hands so that you can flow through your kitchen tasks, like getting down and dirty with food prep, without pausing to turn the faucet handle on and off. And you don't have to worry about spreading the mess, and germs, to the rest of the kitchen.





The state-ofthe-art sensor responds in 20 milliseconds. Simply wave your hand or pot or pan through the sensor window for reliable on/off operation every time.



AUTO SHUTOFF

Sensate_™ features an automatic shutoff safeguard.



Sensate, features DockNetik,, our new magnetic docking system that secures the sprayhead in place.










Response... Technology Delivers convenient, reliable and hygienic control with a swipe of your hand.



DockNetik... Our new docking system features magnets positioned in the spout to securely lock the sprayhead in place.

BEAUTY & BRAWN Sleek design meets a

Sleek design meets a workhorse mentality to help you flow more cleanly and easily through your kitchen.



ProMotion_® Technology

The braided nylon hose ensures it won't kink or tangle, and the swiveling ball joint provides smooth operation with minimal effort.



Two-Function Sprayhead Spray and stream functions help to make light work of kitchen tasks.



Easy Temperature Control Adjust the water temperature with the handle while the faucet is in use.




Battery-Free

AC power means no batteries to replace.

Manual Override

The faucet can be operated manually in the event of a power loss. The sensor window begins at the underside of the spout and extends six inches towards the base. Wave your hand through the beam to activate the water stream.





Finish Options



Sensate Touchless Kitchen FAUCET



Sensate Touchless Kitchen Faucet in Polished Chrome With Black Bonnet With Polished Chrome Bonnet

K-72218-B7-CP K-72218-CP



Sensate Touchless Kitchen Faucet in Vibrant_® Stainless With Black Bonnet With Vibrant Stainless Bonnet

K-72218-B7-VS K-72218-VS



Touchless Operation Delivers convenient and hygienic control



Battery-Free AC power means no batteries to replace



Secure Magnetic Docking Sprayhead securely locks into place

For more information and FAQs, visit KOHLER.com/Sensate.



Lasting Finish Resists corrosion & wear



Durable Ceramic Valves A lifetime of exceptional performance





Easy Clean Wipes clean with a wet cloth



Form 13-1403-0113 © 2013 Kohler Co. Kohler, Wisconsin 53044 Printed in U.S.A. 1-800-4-KOHLER (1-800-456-4537)



KOHLER, Faucets, I ive Bold.